

GAS LASER AND OPTICAL SYSTEM

Inst B1 &gt;

The invention relates to a Helium-Neon gas laser and an optical system used therewith.

Inst B2 &gt;

Typically gas lasers are used in apparatus which rely on the specific frequency of the laser light, for example light having a known wavelength can be used for interferometric measurement. Laser light at a specific frequency is used as a reference to measure the frequency of other light for example in heterodyne frequency measurement systems. Laser spectroscopy requires a light of narrowly defined frequency also. Laser light of a specific polarisation and frequency can be used for polarisation measurement.

Helium-Neon (HeNe) lasers are well suited to these applications since they produce a convenient frequency and are readily controllable.

20

Laser interferometers are shown in Patent Nos. WO98/05955 and US 4,844,593. One subject discussed in these documents is the prevention or reduction of laser output light being reflected back toward the laser (known as "optical feedback" or "back-reflection"). The amount of back-reflection can be determined from known optical parameters of the optical elements used. However, only a small proportion of back-reflected light reaches the laser cavity i.e. approximately 1 to 5 hundredths of the back-reflected light.

30

Back-reflection is undesirable in the devices mentioned above and in all devices which require a specific frequency of laser light, because excessive back-

Sub  
ap >

a' *Conced*  
reflection interacts with the ~~laser~~ to change the polarisation and output frequency of the laser light. Various HeNe lasers suffer from sensitivity to back-reflection.

5

HeNe lasers having gas mixes of varying proportions are known. US Patent No. 4,475,199 describes a ring laser having a HeNe mix consisting of dual isotopes of Ne<sup>20</sup> and Ne<sup>22</sup>. Equal proportions of these two isotopes are

10 mixed with the He. It has now been recognised by the inventor that this mixture when used in a linear laser gives good polarisation stability and hence frequency stability in the resonant cavity of the laser when subjected to back-reflections. Therefore a laser of  
15 this type is ideal for use in back-reflective situations encountered in the devices described above.

*Inst B37*

According to a first aspect of the invention there is provided an optical apparatus comprising a frequency  
20 stabilised linear HeNe gas laser having an Ne content of an Ne<sup>20</sup> isotope and an Ne<sup>22</sup> isotope in substantially equal proportions, the apparatus in use having optical feedback toward the laser causing at least 0.1% of the light output of the laser to be returned toward the  
25 laser.

The optical apparatus may be for example an interferometric displacement determination device; a polarisation measurement device; spectroscopic analysis  
30 apparatus; or a heterodyne frequency measurement device.

Where the optical apparatus is an interferometric displacement determination device, the device may be

any one of a single beam (e.g. Fabry-Perot), a plane mirror, a long range, or an optical fibre type.

Inst B47

The Figure illustrates one embodiment of the invention and shows a plane mirror interferometer including an optical fibre.

Inst B57

The Figure shows a HeNe laser 1 used to provide constant frequency coherent light to an interferometric measurement apparatus 2 via an optical fibre 3. The principle of operation of an interferometer of this type is well known, but briefly:

Optical fibre output beam 4 is split into two by beam splitter 5; reference beam 6 propagates toward fixed mirror 7 and back toward the optical fibre; measurement beam 8 propagates toward movable mirror 9 and back toward the optical fibre. Beams 6 and 8 are combined to form interference fringes. These fringes are detected at detector 10 and counted to provide an indication of the distance moved by mirror 9 in the direction of arrows A.

It follows that in order to determine the displacement of mirror 9, the wavelength of the light used must be known. The more stable the frequency of this light the more accurate is the measurement of displacement.

Back-reflection is particularly problematic in this system because the laser is coupled to an optical fibre. In this system a normally problematic proportion of laser output light i.e. greater than 0.1% is back-reflected toward the laser resonant cavity. This back-reflected light comes from, for example, the

fibre entry, the sides of the fibre, the fibre exit, the fibre core, and a proportion of the light 6 and 8 reflected from mirrors 7 and 9.

5 Thus this apparatus demands stable frequency output at the laser and benefits from a gas laser having a high tolerance to back-reflections. In this instance the resonant cavity of the laser is filled with gas containing 80-90% He and 10-20% Ne. The Ne content is  
10 a dual-isotope of  $\text{Ne}^{20}$  and  $\text{Ne}^{22}$  in substantially equal proportions i.e. any ratio between 60:40 and 40:60 respectively. This gas mixture allows back-reflected light levels in excess of 0.1% of the laser light output, without destabilisation of the output  
15 polarisation. As a result of the polarisation stability, a stable frequency is obtainable also. Such back-reflections may occur continuously or at intervals. The laser achieves a frequency stabilisation below  $1 \times 10^{-7}$  (Frequency noise/Absolute  
20 frequency) when an appropriate frequency control system is used.

Whilst many frequency control methods are known, the preferred method employed is modal control because it  
25 was found to be reliable and cost effective. In this instance mode ratio control was used.

It has been noted by the inventor from experimental results that the back-reflection destabilisation  
30 threshold (i.e. the level of back-reflected light at which a laser becomes unusably unstable) is approximately 10% of laser output for the above-mentioned laser but only about 1% for a conventional "natural" Ne laser i.e. a laser having a  $\text{Ne}^{20}$  to  $\text{Ne}^{22}$

isotope ratio of approximately 9:1 respectively.

The inventor has found also that such a conventional laser with a "natural" (9:1) Ne isotope mix has a slightly better stability compared with the 1:1 Ne isotope mix laser when each is subjected to a back-reflection which is less than about 0.1% of laser light output. Consequently the 1:1 Ne<sup>20</sup> to Ne<sup>22</sup> isotope mix has been found to be best suited to optical apparatus with a relatively high optical feedback i.e. greater than about 0.1% of laser light output.

Other applications of a laser of this type, within the ambit of this invention, are envisaged. For example, the linear laser described above might be used with spectroscopic analysis apparatus, polarisation measurement apparatus, or a heterodyne frequency measurement device each of which may benefit from a laser of the type mentioned above having a stable frequency output, particularly when back-reflections exceed approximately 0.1% of total laser output.

Stabilisation of the laser output frequency may be undertaken by any of the following known techniques:- the "Lamb Dip" technique; general intensity control; Zeeman frequency or intensity control; or modal control either balanced where the intensity of two modes is set to be equal or a ratio of modes, where the intensity ratio of the two modes is fixed.